

# SLEEP MODE

## ACTIVATE Sleep Mode



**1. PRESS & HOLD PAUSE & RESET ON THE COMPANION AT THE SAME TIME (5 SECONDS) UNTIL YOU HEAR A DOUBLE BEEP & 'SL' APPEARS ON THE SCREEN.**

**2. RETURN TO STORAGE FACILITY ONCE CLEARED.**

## DEACTIVATE Sleep Mode



**TO DEACTIVATE SLEEP MODE PRESS & HOLD RESET UNTIL LCD SHOWS 'ON'. IT WILL NOW APPEAR AS A BLUE TILE 'TEST PAD' IN ITS STORE LOCATION.**